

PRELIMINARY SOFTWARE INFORMATION

BVE-9100P Maintenance Program V1.32

Product: **BVE-9100P**

Serial No: **All**

DESCRIPTION

This document provides preliminary information for BVE-9100P Maintenance Program Version 1.32.

NEW FEATURES AND IMPROVEMENTS

The new BKE-9107 hard disk drive (Seagate ST34520N, part number 1-772-867-11) is now supported.

Note: The following software has also been released to support the new BKE-9107 hard disk drive:

Description	Part Number	Documentation
BZE-9101/9102 Operating Software V3.02 for BVE-9100P/9000K	BPE-SS-01BV	PRE-01BV
BVE-9000K Maintenance Program V1.32	BPE-SS-01DC	PRE-01DC
BVE-9100P/9000K ROM 9100M0 V1.11, CPU-88 board	BPE-SS-01DD	PRE-01DD

INSTALLATION PROCEDURE

1. Switch on the BVE-9100P
2. Insert the Maintenance Program disk and boot up the Maintenance Program.
3. Confirm that 'BVE-9100 SYSTEM MAINTENANCE PROGRAM V1.32' is displayed after the BVE-9100P has booted.
4. Remove the Maintenance Program disk from disk drive after the Maintenance Program has booted.

SOFTWARE SET CONTENTS

- This document
- Floppy Disk: Maintenance Program V1.32
- Your licence agreement for the software