

SOFTWARE INFORMATION

MSW-2000 Series : SY V6.08, SV V6.04 (Upgrade by Memory Stick)

Product: **MSW-2000, MSW-A2000, MSW-A2000P, MSW-M2000, MSW-M2000P, MSW-M2100, MSW-M2100P**

Serial No: **All**

DESCRIPTION

SY V6.08 and SV V6.04 software for the MSW-2000 series has been released. This software supersedes SY V6.05 and SV V6.02 .

Note: This software is also registered under BPE-SS-021F for upgrade by Memory Card (refer to document PRE-021F for details).

NEW FEATURE

SY V6.08

The HIF-1 board with suffix -24 for the BKMW-104/1 HD up-converter option board is now supported. This board has the same functionality as boards with lower suffixes and has been introduced for environmental reasons.

Caution: SY V6.08 or higher must be installed if an HIF-1 board with suffix -24 is fitted. SY V6.08 is also compatible with HIF-1 boards with lower suffixes.

IMPROVEMENTS

The following conditions have been corrected:

SY V6.08

1. The picture display shifted eight horizontal lines when CONF1 ENABLE was set during recording.
Note: This condition did not affect the recording and only occurred when SY V6.05 or SY V6.06 was installed.
2. Error message 'Some items do not match!' was displayed whilst attempting to download the setup menu from memory stick or memory card when the unit was in 625 mode and a BKMW-104 HD up-converter option board was fitted.

SV V6.04

If the unit was not fully warmed-up, the S/T tension offset adjustment occasionally failed.

SV V6.03

1. The picture sometimes froze when reverse operation was promptly repeated whilst in JOG/VAR mode during playback of a Betacam SX tape.
2. When the unit was set to PINCH ON and an L cassette was near the end of the tape during FWD or RWD, the tape would slacken.

PROCEDURE FOR CREATING MEMORY STICK

1. Format the memory stick in an MSW-2000 series unit.
2. Download the setup menus to the memory stick.
Note: This will create the required directory structure.
3. Remove the memory stick from VTR and insert it into a PC.
4. Copy the *.BIN files from the PC to the 'STANDARD' sub-directory on the memory stick.

INSTALLATION PROCEDURE

Caution: This procedure should only be used when upgrading from SY V2.05 and higher. To upgrade from SY V1.65 or earlier, refer to the Installation Procedure described in document PRE-01QT.

Upgrade the SY and SV software as described in Section 3-5-11. MEMORY STICK UTIL Mode (M3E) of the Maintenance Manual, Volume 1, Edition 2.

Note: ERROR 96 is displayed when the power is first turned on if the SY software is upgraded from V4.60d or lower. This error can be ignored and will be cancelled by turning the power off and on.

SOFTWARE SET CONTENTS

- This document
- Memory Stick (MSW-2000 series : SY V6.08 + SV V6.04)
- Your licence agreement for the software